

## Instructions - 5522-BATT

## **WARNINGS**

- WARNING: It is recommended that a qualified technician perform the replacement
  of the rechargeable battery pack in this light.
- WARNING: Failure to follow these instructions may impair the intrinsic safety of this flashlight.
- WARNING: To prevent ignition of a hazardous atmosphere, do not open the lens bezel in the hazardous environment. This task must only be performed in an area known to be non-hazardous.
- WARNING: When exchanging the rechargeable battery pack, use only the approved 5522-BATT rechargeable battery pack from bayco products.
- WARNING: To prevent ignition of a hazardous atmosphere, the rechargeable battery pack must only be exchanged in an area known to be non-hazardous.

## REPLACING THE LITHIUM-ION RECHARGEABLE BATTERY

- Loosen the locking screw on the side of the bezel. CAUTION: Do NOT remove the locking screw.
  - Unscrew the lens bezel from the housing in a counter-clockwise direction.
- Loosen each of the two charger contact pins located below the Floodlight Lens.
   These two screws should be loosened until approximately 1/8" of thread is visible.
   CAUTION: Do NOT remove these two screws.
- Turn the light upside down and remove the reflector/circuit assembly. CAUTION:
   Do NOT touch the reflector surface with your finger. Doing so may damage the reflector surface.
- Remove the old 5522-BATT rechargeable battery pack paying attention to the battery pack's orientation within the handle. Please recycle the used battery.
- Using only the approved replacement 5522-BATT rechargeable battery pack from Bayco Products, slide the new battery pack into the handle of the light using the directional arrow marked on the side of the pack as a guide for proper orientation.
- Align the reflector/circuit assembly so that the switches on the assembly are aligned with the switches on the housing. Fully insert the assembly back into the flashlight housing.
- Tighten both of the charger contact screws fully.
- Replace the lens bezel onto the housing in a clockwise direction until tight.
- Tighten locking screw located on the side of the lens bezel. **CAUTION**: Do NOT over-tighten. Doing so may damage the threads.

## **WARRANTY**

2-Year Limited Warranty. Go to www. nightstick.com for warranty information.